

VORTAC SNS 117.3 Chan 120	APP CRS 314°	Rwy Ldg TDZE Apt Elev 163	N/A N/A 163
---	------------------------	--	--------------------------

VOR-A

WATSONVILLE MUNI (WVI)

⚠

⚠

Circling NA west of Rwy 2-20. When local altimeter setting not received, use Monterey altimeter setting and increase all MDAs 80 feet.
DME required. Circling Rwy 27 NA at night.

MISSED APPROACH: Climbing left turn to 5000 direct SNS VORTAC and hold, continue climb-in-hold to 5000.

ASOS 132.275	NORCAL APP CON 127.15 307.125	UNICOM 122.8 (CTAF) 0
------------------------	---	--

